

LEVEL 5 GEN3 INSTALL TEMPLATE INSTRUCTIONS

1. REMOVE ALL DRAWERS FROM TOOLBOX
2. PROPERLY ALIGN TEMPLATE ON TOOLBOX, WHEN IN CORRECT LOCATION USE TAPE TO SECURE TEMPLATE TO TOOLBOX.
 - ACCESS PANEL ON KRL 756 & KRL 1056 TOOL BOXES MUST BE MOUNTED 1-1/8" TO THE RIGHT OF THE MECHANICAL LOCK
 - ACCESS PANEL ON ALL TOOL BOXES EXCEPT KRL 756 & 1056 MUST BE MOUNTED 5-1/8" TO THE LEFT OF THE MECHANICAL LOCK.
3. USE 13/64 TRANSFER PUNCH TO MARK THE CENTER OF THE 9 HOLES TO DRILL
4. DRILL ALL (9) HOLES
 - 4 – 7/32" DIAMETER
 - 4 – 1/2" DIAMETER
 - 1 – 5/8" DIAMETER
5. CUT ALONG DASHED LINE TO JOIN THE ½" DIAMETER HOLES
6. USE SUPPLIED INSTRUCTIONS AND HARDWARE TO INSTALL LEVEL 5 NTC UNIT.